

The laboratory test report and the composition of the Pharma Pack is shown below

**Design of the Pharma Pack to maintain the temp. range: (2°C - 8°C)**



# Pharma Pack : Lab testing report and Parameters

Time In 4 Hrs	Temp In Box	Outside Temperature
0	3.2	30
4	2.8	30
8	3.2	28
12	3.2	28
16	3.8	30
20	4.1	30
24	4.1	28
28	4.8	28
32	5.1	30
36	6	30
40	7.1	29
44	7.9	28
48	7.9	30
52	8.3	30

## Testing Parameters

### Box Size

12x12x12inch  
1.5" pack

### Compositions

Box Top Down

### 3x32 oz gelpacs:

-25 Degree

### 2xFingerpacks:

+3 Degree

### Product Itself

+3 Degree

### 1 Finger-Pack:

+3 Degree

### 1x32 oz Gel-Pack:

-25 Degree